Hospital Disinfectant

Technical Bulletin



Description and Use

Hospital Disinfectant is a TGA Listed hospital-grade disinfectant cleaner for use on all normal washable surfaces. ARTG Number 205434.

Features and Benefits

Hospital Disinfectant contains specialised blends of non-ionic surfactants, sequestrants and quaternary ammonium compounds developed to give outstanding cleaning and disinfection.

Hospital Disinfectant has passed rigorous anti-microbial TGA (Therapeutic Goods Administration) testing and provides disinfection even under dirty conditions.

The product contains eucalyptus oil to give a mild deodorant effect whilst using.

How to Use

Use Hospital Disinfectant at a dilution of 1:40 (½ cup per 5 litres water) on clean or lightly soiled surfaces. Use at a dilution of 1:20 (1 cup per 5 litres) to disinfect and clean soiled surfaces. If soiling is heavy, pre-clean with suitable product and rinse before using Hospital Disinfectant.

Hospital Disinfectant can also be used as a spray and wipe cleaner disinfectant. Use at a dilution of 1:20 (50 ml/L). For floor cleaning, use at a lower concentration of 1:40 (25 ml/L).

Do not mix with any soaps, detergents or other chemicals or deactivation may occur. Not to be used on therapeutic devices.

Usage Instructions / Dilution Rates

Hospital Disinfectant has passed the TGA testing at the concentrations indicated below.

Clean Conditions: Use at 1:40 (25 ml/L) Dirty Conditions: Use at 1:20 (50 ml/L)

Technical Data

Hospital Disinfectant contains alkalis, water softening agents and readily biodegradable detergents for effective cleaning, plus 3.0% quaternary ammonium compound for disinfecting.

It has a pH of 11.6 in the neat form.

Pack Sizes

2 X 5 L Code: 23342

Dominant Colour Code



Hazard Information & Safety

Classified as hazardous according to the criteria of the Globally Harmonised System of Classification and Labelling of Chemicals (GHS).

DANGER

Causes severe skin burns and eye damage Harmful if swallowed

Poisons Schedule: Not Classified Dangerous Goods: Not Classified

Always wear suitable eye and skin protection.



24 Hour Medical Emergency Line 13 11 26 1300 789 852 | enquiry@dominant.com.au | www.domchem.com